

Handshower Wall Bracket Installation Instructions

CALIFORNIA FAUCETS RECOMMENDS THAT ALL PLUMBING PRODUCTS BE INSTALLED BY A LICENSED PROFESSIONAL

IMPORTANT: Read all instructions prior to installation and provide copy of instructions to consumer.

1 PRE-DRILL OF WALL FOR SCREW ANCHOR

- Determine desired location of handshower wall bracket on finished wall surface
- Using appropriate drill bit drill $\varnothing 3/16"$ hole in finished wall
- Insert ANCHOR (1) into drilled hole

2 MOUNTING BRACKET TO WALL

- Removing HOOK (4) from BODY (2)
- Insert SCREW (3) into BODY (2) and securely tighten SCREW (3) into ANCHOR (1)
- Some styles may have sliding flange, this flange shall be slide back to finished wall after body is secured to wall

3 ATTACHING HOOK TO BODY

- Attach HOOK (4) to BODY (2)
- Rotate HOOK (4) completely into BODY (2)
- When HOOK (4) seats against BODY (2), HOOK (4) **MUST** be rotate so that large diameter is toward top
- Tighten SETSCREW (5) with hex KEY (6) provided

